

CAR / TRUCK > CAR / TRUCK - SPECIAL EQUIPMENT



KIT 20 BUSHES FOR BOLTS BMW

Code: **MMO01AXXX0125**

Includes 20 special inserts with 17 mm hexagonal socket, length 37 mm.

TOSI SNC